

FLOWTITE® GRP JACKING PIPES

HANDLING AND STORAGE

TRANSPORT AND HANDLING

FLOWTITE® GRP Jacking Pipes should be stored in their packs until required. Pipes should not be rolled, dropped, thrown or allowed to come into contact with sharp objects that are likely to cause damage, especially to the pipe ends.

Jacking pipes come complete with factory fitted couplings. Pipe jointing lubricant is supplied.

Handling GRP jacking pipes requires the use of soft slings. Steel chains should not be used to lift or handle the pipes.

PACKAGING

FLOWTITE® GRP Jacking Pipes are pre-packed on timbers in the following configurations.

OD RANGE (mm)	CONFIGURATION ACROSS X HEIGHT	QUANTITY PER SEMI-TRAILER IN 2M LENGTHS (m)	QUANTITY PER SEMI-TRAILER IN 3M LENGTHS (m)
350 - 450	5 x 5	250	300
455 - 585	4 x 4	160	192
590 - 800	3 x 3	90	108
805 - 1225	2 x 2	40	48
>1225	1	10	12



The information contained in this document should serve as a guide only and is subject to change without notice. For more information please contact Iplex Pipelines Australia Pty Ltd.

